

## INSTRUCTIONS for Installation in Split System Fan-Coil units



1. Snap packet open and fold top back fully

1. Open fan-coil door and lift one filter out the way
2. Locate opened pack as shown, either horizontally or vertically, making sure opening is uppermost.
3. Put filter back in place and close machine lid.
4. Check pack every 2 months.
5. If empty or near empty, replace with a new pack